


GSM Alarm - Pager

Zapojení GSM Siemens k pageru



- 1 - GND
- 2 - Self service (informace o nabíjení)
- 3 - Load (vstup nabíjecího proudu)
- 4 - Output battery (Vcc)
- 5 - Data TX (data out MT -> PC)
- 6 - Data RX (data in PC -> MT)
- 7 - Detekce / Clock
- 8 - Detekce / Data
- 9 - GND ext. mikrofon
- 10 - Input ext. mikrofon
- 11 - Output ext. audio
- 12 - GND ext. audio

