



R	1,	5,	4,	6,	7,	8, 3,	10, 9,	13,	14,	15, 40, 16,	38, 39, 48,	19,	20, 37,	22, 23,	24,	28, 29, 30, 31, 25,	32,	33,	
C	1,	9, 7, 16, 11, 6,	2, 12, 17, 15,	56,	13, 14, 18, 24,	22, 19, 10, 23, 8, 33, 20, 28,	66, 29,	31, 30,	32,	67,	35, 34, 36,	37,	38, 39,	41, 40, 42, 60, 44, 43, 61,	46,	68, 50,	53, 52,	54, 55,	58, 59, 57,
L	39, 40, 31, 1, 1',	3, 8, 4, 4', 30, 34, 32,	6, 7,	5,	10, 9, 14, 11,	13, 17, 16, 12, 18, 21, 19, 20', 20,	22, 24, 24', 23, 25,	26, 28, 28', 27, 27', 30,	27, 27', 30,	28, 29, 30, 31, 25,	32,	33,	34, 35,	36, 37,	38,	39,	40,	41,	42,



PATICE ELEKTRONIK



TLAČÍTKOVÝ PŘEPÍNAČ P1+P4

TLAČÍTKO OZNAČENÍ	STISKNUTÍM TLAČÍTKA. MĚNÍ SE SPOJENÍ TAKTO :	ROZPOJÍ SE
VK V	P1-1-2, 3-4, 5-6, 7-8, 9-10, 12-13, 15-16, 22-23, 25-26, 32-33	2-3, 4-5, 6-7, 10-11, 13-14, 21-22, 26-27
SV	P2	
OD	P3	11-12, 14-16
VYP	P4	4-6, 11-12, 14-16

ÚDAJE NAPĚTÍ A PROUDŮ NAHOŘE PLATÍ PRO
VELMI KRÁTKÉ VLNĚ, DOLE PRO STŘEDNÍ VLNĚ.
+ MĚŘENO ELEKTRONKOVÝM VOLTMETREM.