



AP1:10 Contactor



The start signal for power unit is connected to board contact G03. The contactor is energised via triac TC102.

AP1:10 Contactor



The start signal for power unit is connected to board contact G03.
The contactor is energised via triac TC102.