


American Honda Motor Co., Inc.

Illustration: CYLINDER □ CRANKCASE (E 01)
GENERATOR, E300, A, JPN



PROGRAMS AND DATA ARE THE PROPERTY OF AMERICAN HONDA MOTOR CO., INC.

Parts List

Ref.	Part Description	Mod.	Qty.	Part Number
001	COVER, CRANKCASE	W	001	11100-812-020
				0100001-1004270
001	COVER, CRANKCASE		001	11100-812-030
				1004271-1018081
001	COVER, CRANKCASE		001	11100-812-040
				1018082-1058040
001	COVER, CRANKCASE		001	11100-812-050
				1058041-1075764
001	COVER, CRANKCASE		001	11100-812-060
				1075765-
002	GASKET, CASE	D	001	11191-812-020
004	CYLINDER		001	12100-812-050
				0100001-1021557
004	CYLINDER		001	12100-812-060
				1021558-1058040
004	CYLINDER		001	12100-812-080
				1075765-
004	CYLINDER		001	12100-812-375
				1058041-1075764
005	CYLINDER HEAD		001	12201-812-010
				0100001-1018081
005	CYLINDER HEAD	W	001	12201-870-000
				1018082-

American Honda Motor Co., Inc.

Illustration: CYLINDER □ CRANKCASE (E 01)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
007	GASKET, CYLINDER HEAD	D	001	12251-812-010 1018082-
007	GASKET, CYLINDER HEAD	Q	001	12251-812-307 0100001-1018081
008	COVER, TAPPET		001	12361-812-010
009	GASKET, TAPPET COVER	D	001	12369-812-010
010	CAMSHAFT	X	001	14101-812-010 0100001-1075764
010	CAMSHAFT	X	001	14101-812-020 1075765-
011	PROTECTOR, GEAR	S	001	14105-836-000
012	VALVE, IN.	X	001	14711-812-020
013	VALVE, EX.	W	001	14721-812-020
014	LIFTER, VALVE	X	002	14731-812-010
015	SPRING, VALVE	X	002	14751-812-000
016	RETAINER, VALVE SPRING	X	002	14771-812-010
017	SEAT, SPRING	X	001	14775-812-000
018	ADJUSTER C, TAPPET CLEARANCE (3.42-3.45)	X	002	14803-812-305 1018082-
018	ADJUSTER F, TAPPET CLEARANCE (3.33-3.36)	X	002	14806-812-305 1018082-
018	ADJUSTER, TAPPET CLEARANCE (3.24-3.27)	X	002	14809-812-305 1018082-
018	ADJUSTER, L. TAPPET CLEARANCE (3.15-3.18)	X	002	14812-812-305 1018082-
018	ADJUSTER, TAPPET CLEARANCE (3.06-3.09)	X	002	14815-812-305 1018082-
019	CAP, OIL	X	001	15620-812-000 0100001-1092170
019	CAP, OIL	X	001	15620-812-010 1092171-2000000
020	BREATHER	X	001	15700-812-000 0100001-1018081
021	TUBE, BREATHER		001	15761-812-020 0100001-1106000
022	INSULATOR, CARBURETOR		001	16211-836-000 0100001-
023	GASKET, CARBURETOR INSULATOR	D	001	16229-812-000
024	BOLT, SPECIAL (5MM)		001	90081-812-000
025	BOLT (10X12)	X	001	90082-704-000
026	WASHER (18MM)		001	90451-812-000 1075765-
027	WASHER (10MM)		001	90472-703-305
028	CIRCLIP (18MM)		001	90601-030-000 1075765-
029	PLUG, CYLINDER SEALING		001	90802-812-000 1058041-1106000
030	OIL SEAL (20X40X6) (AJ-TYPE)	X	001	91202-812-000
031	OIL SEAL (12X22X4) (AJ-TYPE)	X	001	91203-812-010 0100001-1075764
031	OIL SEAL (18X28X5) (AJ-TYPE)		001	91204-812-000 1075765-
032	OIL SEAL (15X24X5)		001	91204-GK8-003
033	O-RING (16MM)		001	91303-800-000 0100001-1092170


American Honda Motor Co., Inc.

Illustration: CYLINDER □ CRANKCASE (E 01)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
------	------------------	------	------	-------------

American Honda Motor Co., Inc.

Illustration: CRANKSHAFT □ PISTON □ RINGS (E 02)
GENERATOR, E300, A, JPN



PROGRAMS AND DATA ARE THE PROPERTY OF AMERICAN HONDA MOTOR CO., INC.

Parts List

Ref.	Part Description	Mod.	Qty.	Part Number
001	CRANKSHAFT ASSY.		001	13000-812-000
				1058041-
003	RING SET, PISTON (STD)	M	001	13010-002-000
003	RING SET, PISTON (OS 0.25)	W	(1)	13021-002-000
003	RING SET, PISTON (OS 0.50)	W	(1)	13031-002-000
003	RING SET, PISTON (0.75)	X	(1)	13041-002-000
004	PISTON (STD)	W	001	13101-812-000
004	PISTON (OS 0.25)	X	(1)	13102-812-000
004	PISTON (OS 0.50)	X	(1)	13103-812-000
004	PISTON (0.75)	X	(1)	13104-812-000
005	PIN, PISTON		001	13111-812-000
006	ROD, CONNECTING	X	001	13200-812-000
				1058041-
007	ROD, CONNECTING		001	13201-812-000
				0100001-1058040
008	BOLT, CONNECTING ROD		002	13203-812-000
				1058041-
009	PLATE, LOCK	X	001	13204-812-000
				1058041-
010	CRANKSHAFT, L.		001	13320-812-020
				0100001-1007891


American Honda Motor Co., Inc.

Illustration: CRANKSHAFT □ PISTON □ RINGS (E 02)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
010	CRANKSHAFT, L.		001	13320-812-030 1007892-1058040
011	CRANKSHAFT, R.		001	13321-812-010 0100001-1024398
011	CRANKSHAFT, R.		001	13321-812-333 1024399-1058040
012	COVER, BEARING		001	13323-812-000 0100001-1058040
013	SCREW, FLAT (5X12)	X	002	93600-05012 0100001-1058040
017	KEY, SPECIAL WOODRUFF (25X18)		001	94401-25180 0100001-1106000
018	CLIP, PISTON PIN (13MM)		002	94601-13000
019	BEARING, RADIAL BALL (6002)		001	96100-60020-00
020	BEARING, RADIAL BALL (6204)	M	001	96100-62040-00

American Honda Motor Co., Inc.

Illustration: GOVERNOR (E 03)
GENERATOR, E300, A, JPN



PROGRAMS AND DATA ARE THE PROPERTY OF AMERICAN HONDA MOTOR CO., INC.

Parts List

Ref.	Part Description	Mod.	Qty.	Part Number
002	PULLEY, TIMING	X	001	14311-812-000
003	PLATE, TIMING PULLEY SIDE	X	001	14315-812-000
004	PULLEY, CAM	X	001	14321-812-000
005	BELT, TIMING	X	001	0100001-1075764
006	SHAFT, THROTTLE	X	001	14401-812-000
006	SHAFT, THROTTLE	X	001	16052-812-020
006	SHAFT, THROTTLE		001	0100001-1026556
006	SHAFT, THROTTLE		001	16562-812-030
006	SHAFT, THROTTLE		001	1026557-1106000
009	SHAFT, ARM	X	001	16530-812-000
009	SHAFT, ARM		001	0100001-1106000
010	ARM, GOVERNOR	X	001	16541-812-000
013	ARM, SPRING	X	001	16544-812-000
014	ROD, GOVERNOR	W	001	16545-812-000
015	SPRING, GOVERNOR	X	001	16551-812-010
015	SPRING, GOVERNOR	X	001	16551-812-303
015	SPRING, GOVERNOR		001	1104806-1106000
016	SCREW, GOVERNOR CONTROL		001	16565-812-000
016	SCREW, GOVERNOR CONTROL		001	0100001-1005269
016	SCREW, GOVERNOR CONTROL		001	16565-812-010
016	SCREW, GOVERNOR CONTROL		001	0100001-1106000
021	LEVER, GOVERNOR SPRING	X	001	16570-812-000


American Honda Motor Co., Inc.

Illustration: GOVERNOR (E 03)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
023	SCREW, ADJUSTING	X	001	16575-812-000 0100001-1104805
023	SCREW, ADJUSTER		001	16575-812-303 1104806-1106000
026	SPRING, LOCK (3.6MM)	X	001	16618-812-000
027	LEVER, CHOKE	X	001	16621-812-000
028	SPRING, CHOKE ADJUSTING		001	16623-812-000
029	HOLDER, STARTER PAWL	X	001	28440-812-000 0100001-
030	RING, SNAP (3.2MM)	X	001	30158-700-000
031	BOLT, SPECIAL (5MM)	X	001	90001-812-010
032	NUT, SPECIAL (12MM)	X	001	90281-812-000
033	O-RING (4MM)	X	001	90305-812-000 0100001-1106000
034	WASHER, SPECIAL (7MM)		001	90401-812-000
035	GUIDE, CHOKE ADJUSTING	X	001	16617-812-010
035	WASHER, LOCK (12MM)		001	90432-812-010
036	WASHER, SPECIAL (5MM)	X	001	90474-812-000 0100001-1075764
038	PIN, KNOCK (4MM)	X	001	90701-812-000 0100001-1075764
039	BEARING, BALL (609UU)	X	001	91001-812-000 1024399-1058040
040	BOLT, HEX. (5X14)	S	001	92000-05014-0A 0100001-1075764
040	BOLT, HEX. (5X14)		001	92101-05014-0A 0100001-1075764
048	WASHER, SPRING (5MM)		001	94111-05000 0100001-1075764
049	PIN, DOWEL (7X12)		002	94301-07120
051	KEY, WOODRUFF (16X12)		001	94401-16120
053	BALL, STEEL (#5) (5/32)		001	96211-05000 0100001-1106000

American Honda Motor Co., Inc.

Illustration: MUFFLER (E 04)
GENERATOR, E300, A, JPN



PROGRAMS AND DATA ARE THE PROPERTY OF AMERICAN HONDA MOTOR CO., INC.

Parts List

Ref.	Part Description	Mod.	Qty.	Part Number
001	ELEMENT, AIR CLEANER	X	001	17211-812-000
				0100001-1040209
001	ELEMENT, AIR CLEANER	X	001	17211-812-010
				1040210-1106000
002	GRID, FILTER	X	001	17212-812-000
				0100001-1040209
002	GRID, FILTER		002	17212-812-010
				1040210-1106000
003	PIPE, AIR CLEANER		001	17214-812-000
				1040210-1106000
004	COVER, CLEANER ELEMENT		001	17215-812-000
				1040210-1106000
005	PIPE, EX.		001	18211-812-000
				0100001-1018081
005	PIPE, EX.	X	001	18211-812-010
				1018082-1079915
005	PIPE, EX.		001	18211-812-020
				1079916-1106000
006	GASKET, EX. PIPE	D	001	18232-812-000
				0100001-1021557
006	GASKET, EX. PIPE	D	001	18232-812-010
				1021558-
007	GASKET, MUFFLER	X	001	18241-812-000
				1079916-1106000


American Honda Motor Co., Inc.

Illustration: MUFFLER (E 04)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
008	NUT, MUFFLER SETTING		001	18251-812-000 1079916-1106000
009	MUFFLER	S	001	18300-812-020 1079916-1106000
009	MUFFLER		001	18300-812-315 0100001-1079915
010	SEAL, EX. PIPE	X	001	18351-812-010 0100001-1079915
011	PROTECTOR, MUFFLER	S	001	18361-812-010 0100001-1106000
012	STOPPER, PROTECTOR		001	18369-812-010
013	LID, MUFFLER	X	001	18371-812-000 0100001-1079915
014	GASKET, MUFFLER LID	D	001	18372-812-000 0100001-1079915
015	COVER, FAN		001	19600-812-020 0100001-
016	GASKET, CLEANER COVER		001	19603-812-300 0100001-1040209
016	GASKET, CLEANER	X	001	19616-812-310 1040210-1106000
017	VANE A, GUIDE		001	19610-812-010 0100001-1018081
017	VANE A, GUIDE		001	19610-812-020 1018082-1106000
018	VANE B, GUIDE		001	19620-812-010 0100001-1021557
018	VANE B, GUIDE		001	19620-812-020 1021558-1085007
018	VANE B, GUIDE		001	19620-812-030 1085008-
019	RUBBER, GUIDE	X	001	63371-812-010 0100001-1021557
020	BOLT, HEX. (5X8)		006	92101-05008-0A 0100001-1106000
022	BOLT, HEX. (5X55)	S	002	92000-05055
022	BOLT, HEX. (5X55)	X	002	92000-05055-0A
023	BOLT, HEX. (8X12)	S	002	92000-08012-0A 1079916-1106000
023	BOLT, HEX. (8X12)	X	002	92100-08012-0A 1079916-1106000
023	BOLT, HEX. (5X18)		001	92101-05018-0A 1106001-
024	BOLT, HEX. (5X10)	M	004	92101-05010-0A 0100001-1106000
026	BOLT, HEX. (5X10)	M	002	92101-05010-0A 0100001-1106000
028	SCREW, PAN (5X8)		005	93500-05008-0A 0100001-1106000
029	SCREW, PAN (5X18)		002	93500-05018-0A 0100001-1106000
030	SCREW, FLAT (5X22)		002	93600-05022 1040210-1106000
031	NUT, HEX. (5MM)	M	001	94001-05000-0S 1106001-
032	NUT, HEX. (6MM)	M	002	94001-06000-0S
032	NUT, HEX. (6MM)	M	002	94001-06200-0S

American Honda Motor Co., Inc.

Illustration: EK1 K2 CARBURETOR (E 05)
GENERATOR, E300, A, JPN



PROGRAMS AND DATA ARE THE PROPERTY OF AMERICAN HONDA MOTOR CO., INC.

Parts List

Ref.	Part Description	Mod.	Qty.	Part Number
001	TUBE, CARBURETOR DRAIN	X	001	15777-812-000 1006203-2000000
002	VALVE SET, FLOAT		001	16011-866-004 -2000000
003	SCREW SET, DRAIN	X	001	16024-812-004
004	CARBURETOR ASSY.	X	001	16100-812-014
005	CUP, FLOAT	D	001	16121-812-004
006	FLOAT SET (N/A: USE P/N 16013-812-004) (ALT. PNO: 16013-812-004)	D	001	16122-812-004
007	GASKET SET	D	001	16174-204-004
008	ROD, GOVERNOR	W	001	16545-812-000
009	ROD, CHOKE	X	001	16625-812-000
010	TUBE ASSY., FUEL	X	001	16850-812-000 0100001-1004270
010	TUBE ASSY., FUEL	X	001	16850-812-010 1004271-1240000
011	TUBE, FUEL	X	001	16851-812-000 0100001-1004270
011	TUBE, FUEL	S	001	16851-812-010 1004271-1240000
011	BULK HOSE, FUEL (4.5X3000) OEM CUT SIZE: (4.5X143)		001	95001-45003-50M 1004271-1240000


American Honda Motor Co., Inc.

Illustration: EK1 K2 CARBURETOR (E 05)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
012	TUBE, VALVE BREATHER	X	001	16852-812-000
013	TUBE, CARBURETOR OVERFLOW	X	001	16853-812-000
014	RUBBER A, SUPPORTER		001	16854-812-000
014	RUBBER, SUPPORTER		001	16854-836-010
015	RUBBER B, SUPPORTER		001	16855-812-000
016	NUT, HEX. (5MM)	M	002	94001-05000-0S
018	CLIP, TUBE (C8)		002	95002-45000 0100001-
019	JET, MAIN (#55)	X	001	99108-05504 0100001-1106000
021	JET, PILOT (#35)		001	99157-03504

American Honda Motor Co., Inc.

Illustration: EK1 K2 ALTERNATOR □ POINTS (F 01)
GENERATOR, E300, A, JPN



PROGRAMS AND DATA ARE THE PROPERTY OF AMERICAN HONDA MOTOR CO., INC.

Parts List

Ref.	Part Description	Mod.	Qty.	Part Number
001	POINTS ASSY., CONTACT	X	001	30200-812-000 0100001-1007410
001	POINTS ASSY., CONTACT	X	001	30200-812-010 1007411-1106000
002	POINTS ASSY., CONTACT	X	001	30200-812-000
002	POINTS ASSY., CONTACT	X	001	30200-812-010 0100741-1106000
003	BASE		001	30201-812-003 1067411-1106000
003	BASE		001	30201-812-305 0100001-1067410
004	CONDENSER ASSY.	X	001	30203-812-003
005	COVER, POINTS		001	30211-812-010 0106771-
005	COVER, POINTS	X	001	30211-812-305 0100001-0106770
006	BOLT, POINTS SET		002	30213-812-010
006	SCREW, PAN (5X12)		002	93500-05012-0A 1067701-1106000
008	COIL ASSY., A.C. IGNITION	X	001	30500-812-013
009	COLLAR A, IGNITION DISTANCE	X	001	30531-812-000
010	COLLAR B, IGNITION DISTANCE		001	30532-812-000 0100001-

American Honda Motor Co., Inc.

Illustration: EK1 K2 ALTERNATOR □ POINTS (F 01)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
011	COVER, IGNITION TERMINAL	X	001	30611-812-000 0100001-1022091
012	TERMINAL ASSY., IGNITION	X	001	30615-812-010 1022092-
012	TERMINAL ASSY., IGNITION		001	30616-812-000 0100001-
013	SUPPRESSOR, NOISE	X	001	30700-812-000 0100001-1022091
013	SUPPRESSOR, NOISE	X	001	30700-812-010 1022092-
014	STATOR ASSY., ALTERNATOR		001	31150-812-033 0100001-1007891
014	STATOR ASSY., ALTERNATOR		001	31150-812-043 1007892-1011454
014	STATOR ASSY., ALTERNATOR		001	31150-812-053 1011455-1070621
014	STATOR ASSY., ALTERNATOR		001	31150-812-060 1070622-1099383
014	STATOR ASSY., ALTERNATOR		001	31150-812-631 1099384-1106000
015	TUBE A, RUBBER		001	31156-836-000 1022235-2000000
016	CLAMP, JOINT		001	31157-812-000 1022235-2000000
017	ROTOR, ALTERNATOR		001	31160-812-003
018	REACTOR		001	31170-812-023 0100001-1099383
018	REACTOR		001	31170-812-631 1099384-1106000
019	BEARING, NEEDLE		001	31191-812-000 0100001-1007891
019	BEARING, RADIAL BALL (6001UU)		001	96150-60010-10 1007892-
020	OIL SEAL		002	31192-812-000 0100001-1007891
021	RECTIFIER, SILICON		001	31700-812-000 1028067-1106000
022	CLAMP, WIRE		001	32901-812-000 0100001-2000000
023	NUT, SPECIAL (16MM)		001	90282-812-000
024	BOLT, HEX. (6X103)	W	003	92000-06103
024	BOLT, HEX. (6X145)	W	001	92000-06145
025	SCREW, PAN (4X6)		001	93500-04006-0A
026	SCREW, PAN (4X6)		002	93500-04006-0A 0100001-1106000
027	SCREW, PAN (4X20)	Z	002	93500-04020 1028067-
027	SCREW, PAN (4X20)		002	93500-04020-0A 1028067-
028	SCREW, PAN (5X8)		004	93500-05008-0A
029	SCREW, PAN (5X30)		001	93500-05030-0A
030	SCREW, PAN (5X42)	X	001	93500-05042
032	WASHER, PLAIN (4MM)		002	94101-04000 1028067-
033	WASHER, PLAIN (6MM)		002	94101-06800 0100001-1067410
034	WASHER, FLAT (16MM)		001	94101-16000
035	WASHER, SPRING (4MM)		001	94111-04000


American Honda Motor Co., Inc.

Illustration: EK1 K2 ALTERNATOR □ POINTS (F 01)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
------	------------------	------	------	-------------

American Honda Motor Co., Inc.

Illustration: STARTER PULLEY □ RECOIL STARTER (F 02)
GENERATOR, E300, A, JPN



PROGRAMS AND DATA ARE THE PROPERTY OF AMERICAN HONDA MOTOR CO., INC.

Parts List

Ref.	Part Description	Mod.	Qty.	Part Number
001	CASE, SPRING	W	001	11400-812-060 1058041-1106000
001	CASE, SET SPRING		001	11400-812-325 0100001-1005269
001	CASE, SET SPRING		001	11400-812-345 1005270-1058040
002	FELT (5.5MM)		001	11511-812-000 0100001-1058040
002	FELT (5.5MM)	X	001	11511-812-010 1058041-1106000
003	WEIGHT, GOVERNOR	X	006	16511-800-000
004	RING, GOVERNOR		001	16515-812-000
005	SLIDER, GOVERNOR	X	001	16520-812-000
006	FAN, COOLING		001	19510-812-010 0100001-1024398
006	FAN, COOLING	X	001	19510-812-020 1024399-1058040
006	FAN, COOLING	X	001	19510-812-030 1058041-1106000
007	PLATE, COOLING FAN		001	19515-812-010 0100001-1024398
007	PLATE, COOLING FAN		001	19515-812-010 1009666-1024398


American Honda Motor Co., Inc.

Illustration: STARTER PULLEY □ RECOIL STARTER (F 02)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
010	PULLEY, STARTER		001	28420-812-000 0100001-1058040
010	PULLEY, STARTER		001	28420-812-010 1058041-1106000
011	PLATE, STARTER		001	28425-812-000 0100001-1106000
012	RATCHET, STARTER	X	001	28441-812-000 0100001-1106000
013	SPRING, STARTER	X	001	28450-812-000 0100001-1106000
014	GRIP, STARTER	X	001	28461-812-010 0100001-1106000
015	ROPE, RECOIL STARTER (#4X55")	M	001	28462-ZA7-003
015	ROPE, STARTER (#4X65")	M	001	28462-ZA8-901
015	ROPE (#4X55")		001	28462-ZE6-T02
016	GUIDE, STARTER ROPE	X	001	28475-812-000 0100001-1106000
017	BOLT, SPECIAL (4MM)		001	90082-812-000 0100001-1106000
021	SCREW, FLAT (4X8)	X	003	93600-04008 1009666-1024398
022	SCREW, FLAT (5X16)	X	004	93600-05016 0100001-1106000
023	WASHER, PLAIN (10MM)		001	94102-10000 -2138535
024	CIRCLIP (OUTER) (21MM)	X	001	90602-703-000 1058041-1106000
024	CIRCLIP (OUTER) (18MM)		001	94510-18000 0100001-1058040

American Honda Motor Co., Inc.

Illustration: COVER □ AIR CLEANER (F 03)
GENERATOR, E300, A, JPN



PROGRAMS AND DATA ARE THE PROPERTY OF AMERICAN HONDA MOTOR CO., INC.

Parts List

Ref.	Part Description	Mod.	Qty.	Part Number
001	TUBE, AIR CLEANER	S	001	17111-836-000
001	TUBE, AIR CLEANER	X	001	17111-866-000
002	TUBE, IN. MUFFLER CONNECTING	W	001	17121-836-000
003	MUFFLER, IN.	X	001	17131-836-000
004	GASKET, IN. MUFFLER	D	001	17132-836-000
005	ELEMENT, AIR CLEANER		001	17211-836-000
008	HOLDER, SPARE PLUG		001	38211-812-010
009	COVER, FR. *R15L* (WINE RED)		001	63310-812-030J
011	LATCH, COVER		002	63381-812-010
012	PIN, LATCH SNAP		002	63387-812-000
				0100001-1106000
013	COVER, RR. *R15L* (WINE RED)	001		63410-812-010J
013	COVER, RR. *R15L* (WINE RED)	001		0100001-1088364
014	COVER, R. SIDE	001		63410-812-020J
				1088365-
		001		63510-812-010
				0100001-1106000
015	STOPPER, LATCH	X	003	63588-801-000
				1106001-
017	COVER, L. SIDE	001		63610-812-010
				0100001-1106000


American Honda Motor Co., Inc.

Illustration: COVER □ AIR CLEANER (F 03)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
018	MARK, TOP		001	87101-812-630
019	MARK, FR.	X	001	87111-812-630
020	PLATE, NAME	X	001	87151-812-630
				0100001-1088449
020	PLATE, NAME		001	87151-812-810
				1088450-1106000
021	PLATE, CAUTION	X	001	87521-812-630
023	MARK A, OIL CHECK		001	87541-836-681
				1034590-1106000
024	MARK B, OIL CHECK		001	87542-812-630
				1034590-
025	SCREW, PAN (5X8)		010	93500-05008-0A
026	SCREW, PAN (5X20)	M	002	93500-05020-0A
				1000001-3110772
027	SPARK PLUG (CM6) (NGK)		001	98052-56471

American Honda Motor Co., Inc.

Illustration: FUEL TANK □ PANEL (F 04)
GENERATOR, E300, A, JPN



PROGRAMS AND DATA ARE THE PROPERTY OF AMERICAN HONDA MOTOR CO., INC.

Parts List

Ref.	Part Description	Mod.	Qty.	Part Number
004	NUT, KNOB	X	002	16563-812-010 0100001-1026556
005	KNOB, CONTROL	X	002	16564-812-010 0100001-1026556
005	KNOB, CONTROL		002	16564-812-020 1026557-
006	GASKET, STRAINER SETTING	X	002	16913-703-000 0100001-2025090
007	PETCOCK ASSY.	X	001	16950-812-010 0100001-1026556
007	PETCOCK ASSY.		001	16950-836-015 1026557-
008	BODY, FUEL LEVER	X	001	16951-812-004
009	CAP, PETCOCK	X	001	16956-812-010 0100001-2039313
010	LEVER, VALVE	X	001	16957-812-000 0100001-1026556
010	LEVER, VALVE	X	001	16957-812-010 1026557-2000000
011	GASKET A, PETCOCK	X	001	16958-812-004 0100001-2039313
012	GASKET, VALVE		001	16960-812-004 0100001-2039313

American Honda Motor Co., Inc.

Illustration: FUEL TANK □ PANEL (F 04)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
013	FILTER, CHECK	X	001	16962-812-004 0100001-2039313
014	PLATE, LEVER		001	16964-812-000 0100001-2039313
015	GASKET, O-TYPE	X	001	16966-812-004 0100001-2039313
016	COLLAR, LEVER GASKET		001	16968-812-000 0100001-2039313
017	SPRING, PETCOCK LEVER	X	001	16975-805-000 0100001-203913
018	FILTER, CHECK	X	001	16981-836-700 0100001-2039313
019	TANK, FUEL	S	001	17500-812-030
020	TUBE, HANDLE BREATHER	X	001	17601-812-010
021	CAP, TANK	X	001	17650-801-020
022	FILTER, FUEL	S	001	17672-812-000
023	RUBBER, FILTER	X	001	17673-836-000
024	CONNECTOR A, FUSE	X	001	32112-253-010
024	CONNECTOR A, FUSE (RED)		001	32343-812-000
026	RECEPTACLE ASSY., SWITCH		001	32340-812-010 0100001-1101454
026	RECEPTACLE ASSY., SWITCH		001	32340-812-033 1099384-1106000
026	RECEPTACLE ASSY., SWITCH	X	001	32340-812-303 1101455-1099383
027	SWITCH ASSY., CHANGE		001	32341-812-000 0100001-1013194
027	SWITCH ASSY., CHANGE	X	001	32341-812-010 1013195-1099383
028	CONNECTOR B, FUSE (RED)		001	32344-812-000
028	CONNECTOR B, FUSE (WHITE)		001	32345-812-000
029	SCREW, PAN (2X4)		002	32346-812-000
030	WASHER		002	32347-812-000
032	BULB, DASH	X	001	32348-812-000 1000001-1011454
032	BULB, DASH (6V3W) (STANLEY)		001	34902-202-000 1011455-
033	SOCKET ASSY.		001	32349-812-010 1099348-1106000
034	SWITCH ASSY., ENGINE	X	001	36100-836-005 0100001-1240000
035	ARM, SWITCH	X	001	36141-812-000
036	METER, CYCLE		001	37500-812-000 0100001-1099383
036	METER, FREQUENCY		001	37500-812-153 1099384-1106000
038	FUSE (3A)	S	001	38218-812-010 0100001-
038	FUSE ASSY., SPARE		001	38218-836-730 0100001-
039	RUBBER, GUIDE	X	004	63371-812-010
040	PANEL, FR.	S	001	66211-812-010 0100001-1005679
040	PANEL, FR.	X	001	66211-812-020 1005680-1106000
041	HANDLE, CARRY		001	68110-812-020


American Honda Motor Co., Inc.

Illustration: FUEL TANK □ PANEL (F 04)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
042	COVER, HANDLE	X	001	68121-812-000
043	HOOK, HANDLE COVER		002	68125-812-000
044	GASKET A, HANDLE	X	001	68141-812-010
045	GASKET B, HANDLE	X	001	68142-812-000
046	MARK, VALVE KNOB	X	001	87531-812-010 0100001-1106000
047	MARK, THROTTLE KNOB		001	87532-812-010
048	MARK, CONTROL KNOB	X	002	87533-812-000 1026441-
049	TOOL ASSY. (N/A: SEE COMPONENTS)	D	001	89000-836-000
050	WRENCH (9MM) (OPEN END)	W	001	89203-812-000
051	WRENCH, SPARK PLUG	D	001	89216-812-010 1000001-
052	RUBBER, FRICTION	D	001	89218-812-000
053	SCREWDRIVER	W	001	89221-812-000
054	SCREW, STOP (3MM)		002	90192-801-010 1026557-
055	O-RING (5X1.5)	X	002	91301-801-000
056	SCREW, PAN (3X6)	X	004	93500-03006-0B
057	SCREW, PAN (3X6)	X	001	93500-03006-0B 0100001-1106000
058	SCREW, PAN (4X8)		002	93500-04008-0A
059	SCREW, PAN (5X8)		003	93500-05008-0A
060	SCREW, PAN (6X16)		002	93500-06016-0A
061	SCREW, PAN (6X20)	Z	002	93500-06020
061	SCREW, PAN (6X20)		002	93500-06020-0A
062	FUSE A (7A)		001	98200-10700

American Honda Motor Co., Inc.

Illustration: LOWER COVER (F 05)
GENERATOR, E300, A, JPN



PROGRAMS AND DATA ARE THE PROPERTY OF AMERICAN HONDA MOTOR CO., INC.

Parts List

Ref.	Part Description	Mod.	Qty.	Part Number
001	RUBBER (LOWER)		004	60407-812-000
002	RUBBER, GUIDE	X	004	63371-812-010
003	COVER (LOWER) *NH1* (BLACK)	X	001	63700-866-000B 1106001-

American Honda Motor Co., Inc.

Illustration: LOWER COVER (F 05)
GENERATOR, E300, A, JPN

Ref.	Part Description	Mod.	Qty.	Part Number
003	COVER (LOWER)		001	63720-812-010 0100001-1106000
004	RUBBER, SETTING STOPPER	X	004	63725-836-000
005	FRAME, ENGINE	X	001	68310-836-010
006	FRAME, ALTERNATOR	X	001	68320-836-010 0100001-1114964
007	WASHER (6MM)		004	90539-836-000
008	SCREW, PAN (5X10)		004	93500-05010-0A
009	SCREW, PAN (5X10)		004	93500-05010-0A 0100001-2049990
010	SCREW, PAN (5X12)		004	93500-05012-0A
011	WASHER, SPRING (5MM)		004	94111-05000